



Instructions for “Emergency Update” error

- Download Update files and save to HD
- Open .RAR file and extract SYSTEM folder
- Copy SYSTEM folder to the root of any SD card (If using the Navigation card that comes with the unit **DO NOT ERASE ANY OF THE FILES ALREADY ON THIS CARD**, these are the Navigation software.)



- Open SYSTEM folder and copy these files
- Paste files to the root of SD card



- Lock SD card and insert while unit is off



- Turn on unit and wait for it to finish booting (In some cases the unit will boot into the home screen and not update automatically, in this case go to the setup menu-Software-Start update.)
- After update is finished, remove SD card and UNLOCK it (If using the Nav card to update, go back to computer and erase only the files for updating and nothing else.)